v2-02.07

COMECO
CONTROL & MEASUREMENT

COMECO Ltd., P.O.Box 378, Plovdiv 4000, BULGARIA, tel: +359 32 646523, 646524, fax: 634089
e-mail: info@comeco.org, WWW.COMECOGROUP.COM

RH PROBE FOR HANDHELD METER

RHA

OPERATION MANUAL

Please read this Operation Manual before mounting and operating!
Save the Manual for future references!

Wiring

- Connect the probe to the handheld meter via the connector.
- If connector replacement is necessary, mind its pin connections.

Specifications

RH Input Range	0...100% RH
Build-in Temperature Sensor	☐ Pt100, ☐ Pt1000
Temperature Input Range	-10…50 °C
Output Signal	..... mV DC
Power Supply	5 VDC from the handheld meter
Permissible Supply Voltage Deviations	20 mV peak-to-peak, at 50 Hz
Accuracy	2.5% from span
Temperature Drift	0.1% from span for 1 °C
Operating Temperature	-10…50 °C
Storage Temperature	-20…80 °C
Protection Class	IP54 (excl. sensor)

Warranty and Support

……

manufacturing date

QC check mark ……(passed)

(signature, stamp)

88 Slavyanska Str.
P.O.Box 378
Plovdiv 4000, BULGARIA
tel: +359 32 646523, 646524
fax: +359 32 634089, 622719
e-mail: support@comeco.org

Warranty

COMECO warrants this product to be free from defects in materials and workmanship for one year. If your unit is found to be defective within that time, we will promptly repair or replace it. This warranty does not cover accidental damage, wear or tear, or consequential or incidental loss. This warranty does not cover any defects caused by wrong transportation, storage, installation, or operating (see '**Specifications**').

Technical support

In the unlikely event that you encounter a problem with your COMECO device, please call your local dealer or contact directly our support team.